

Cardwell Suit Sizing Chart

Single Layer, Double Layer, Triple Layer)

Unit: cm

Parts	XS	S	M	MT	L	XL	XL-1	2XL	2XL-1	3XL	4XL	5XL
A. CHEST Circumference at arm pits	101	106	109	114	119	123	127	131	136	142	152	163
Tolerance ± 2cm												
B. WAIST Stretched circumference at middle belt	83	89	91	96	101	105	111	116	121	127	148	158
Tolerance ± 2cm												
C. HIPS Circumference 9" below centre of belt	100	101	105	108	111	115	119	123	129	133	145	158
Tolerance ± 2cm												
D. THIGH Circumference 3" below crotch seam	57	59	61	64	65	68	70	72	73	76	81	87
Tolerance ± 1cm												
E. COLLAR Length of collar, end to end	43	45	48	49	51	52	53	55	56	58	59	62
F. SLEEVE Shoulder point to end of sleeve	51	54	57	59	60	61	63	65	69	69	73	74
Tolerance ± 1cm												
G. ARM HOLE Length of seam around arm cap	51	53	54	55	55	60	61	63	63	65	68	70
H. MID-FOREARM Circumference of sleeve 3" above sewn cuff	32	32	34	35	37	39	39	40	40	42	45	47
I. FT NECK TO WAIST Side neck point to middle of belt	49	50	53	54	55	57	58	59	59	60	66	69
Tolerance ± 1cm												
J. BACK NECK TO WAIST From bottom of collar to middle of belt	49	50	51	52	54	56	57	58	58	59	65	67
Tolerance ± 1cm												
K. WAIST TO END OF LEG Middle of belt to end of leg	93	94	95	96	97	97	98	100	101	102	103	108
Tolerance ± 2cm												
L. INSEAM Center of crotch seam, along inside of leg to end of cuff	69	69	70	70	70	70	71	73	73	73	75	80
Tolerance ± 1cm												
M. CROTCH Front waist through legs to middle of back belt	61	64	64	65	66	66	70	69	68	70	70	76
Tolerance ± 1cm												
N. MIDCALF Circumference of leg 3" above sewn cuff	35	38	40	43	45	46	47	48	49	50	53	55
Q. SHOULDER Back width	44	45	49	50	52	53	54	55	57	58	61	65
Tolerance ± 1cm												

How to Measure

